

How to determine Proper Carb size

1. Take Cubic Inches and multiply by maximum RPM range vehicle will achieve.
2. Divide 3456 into this number.

Example :

$$\frac{350 \text{ ci} \times 6,000}{3456}$$

608 cu inches maximum necessary